# Federal Aviation Administration, DOT

(d) Paragraphs (b)(1) through (b)(3) and paragraph (c) of this section do not apply to aircraft for which a maximum operating speed  $V_{MO}/M_{MO}$  is established under 23.1505c. For those aircraft there must either be a maximum allowable airspeed indication showing the variation of  $V_{MO}/M_{MO}$  with altitude or compressibility limitations (as appropriate), or a radial red line marking for  $V_{MO}/M_{MO}$  must be made at lowest value of  $V_{MO}/M_{MO}$  established for any altitude up to the maximum operating altitude for the airplane.

[Doc. No. 4080, 29 FR 17955, Dec. 18, 1964, as amended by Amdt. 23–3, 30 FR 14240, Nov. 13, 1965; Amdt. 23–7, 34 FR 13097, Aug. 13, 1969; Amdt. 23–23, 43 FR 50593, Oct. 30, 1978; Amdt. 23–50, 61 FR 5193, Feb. 9, 1996]

EFFECTIVE DATE NOTE: By Amdt. 23–62, 76 FR 75762, Dec. 2, 2011, §23.1545 was amended by revising paragraph (d), effective Jan. 31, 2012. For the convenience of the user, the revised text is set forth as follows:

#### §23.1545 Airspeed indicator.

\* \* \* \* \*

(d) Paragraphs (b)(1) through (b)(4) and paragraph (c) of this section do not apply to airplanes for which a maximum operating speed  $V_{\rm MO}/M_{\rm MO}$  is established under  $\S23.1505(c).$  For those airplanes, there must either be a maximum allowable airspeed indication showing the variation of  $V_{\rm MO}/M_{\rm MO}$  with altitude or compressibility limitations (as appropriate), or a radial red line marking for  $V_{\rm MO}/M_{\rm MO}$  must be made at lowest value of  $V_{\rm MO}/M_{\rm MO}$  established for any altitude up to the maximum operating altitude for the airplane.

## § 23.1547 Magnetic direction indicator.

- (a) A placard meeting the requirements of this section must be installed on or near the magnetic direction indicator.
- (b) The placard must show the calibration of the instrument in level flight with the engines operating.
- (c) The placard must state whether the calibration was made with radio receivers on or off.
- (d) Each calibration reading must be in terms of magnetic headings in not more than 30 degree increments.
- (e) If a magnetic nonstabilized direction indicator can have a deviation of more than 10 degrees caused by the operation of electrical equipment, the

placard must state which electrical loads, or combination of loads, would cause a deviation of more than 10 degrees when turned on.

[Doc. No. 4080, 29 FR 17955, Dec. 18, 1964; 30 FR 258, Jan. 9, 1965, as amended by Amdt. 23–20, 42 FR 36969, July 18, 1977]

# § 23.1549 Powerplant and auxiliary power unit instruments.

For each required powerplant and auxiliary power unit instrument, as appropriate to the type of instruments—

- (a) Each maximum and, if applicable, minimum safe operating limit must be marked with a red radial or a red line;
- (b) Each normal operating range must be marked with a green arc or green line, not extending beyond the maximum and minimum safe limits;
- (c) Each takeoff and precautionary range must be marked with a yellow arc or a yellow line; and
- (d) Each engine, auxiliary power unit, or propeller range that is restricted because of excessive vibration stresses must be marked with red arcs or red lines.

[Amdt. 23–12, 41 FR 55466, Dec. 20, 1976, as amended by Amdt. 23–28, 47 FR 13315, Mar. 29, 1982; Amdt. 23–45, 58 FR 42166, Aug. 6, 1993]

## §23.1551 Oil quantity indicator.

Each oil quantity indicator must be marked in sufficient increments to indicate readily and accurately the quantity of oil.

### §23.1553 Fuel quantity indicator.

A red radial line must be marked on each indicator at the calibrated zero reading, as specified in §23.1337(b)(1).

[Doc. No. 27807, 61 FR 5193, Feb. 9, 1996]

### §23.1555 Control markings.

- (a) Each cockpit control, other than primary flight controls and simple push button type starter switches, must be plainly marked as to its function and method of operation.
- (b) Each secondary control must be suitably marked.
  - (c) For powerplant fuel controls—
- (1) Each fuel tank selector control must be marked to indicate the position corresponding to each tank and to each existing cross feed position;